

Turtle Tank Penetrations



Notes for Penetrations:

Six drill holes should allow sledge to break through. Hole is approximately 9" by 5"
T fittings can be mortared or quikset hydraulic cement or consealed or acoustic sealant.
A T-handle should be screwed into effluent filter to access filter in deep buried tank.

